


WIRING INSTALLATION



CALIBRATION TABLE

0 - 4000 Rpm GAUGE

Cyl	1000 Rpm	2000 Rpm	3000 Rpm	4000 Rpm
1	75 Hz	150 Hz	225 Hz	300 Hz
2	115 Hz	230 Hz	345 Hz	460 Hz
3	145 Hz	290 Hz	435 Hz	580 Hz
4	205 Hz	410 Hz	615 Hz	820 Hz
5	290 Hz	580 Hz	870 Hz	1160 Hz
6	430 Hz	860 Hz	1290 Hz	1720 Hz

0 - 6000 Rpm GAUGE

Cyl	1000 Rpm	2000 Rpm	3000 Rpm	4000 Rpm	5000 Rpm	6000 Rpm
1	75 Hz	150 Hz	225 Hz	300 Hz	375 Hz	450 Hz
2	115 Hz	230 Hz	345 Hz	460 Hz	575 Hz	690 Hz
3	145 Hz	290 Hz	435 Hz	580 Hz	725 Hz	870 Hz
4	205 Hz	410 Hz	615 Hz	820 Hz	1025 Hz	1230 Hz
5	290 Hz	580 Hz	870 Hz	1160 Hz	1450 Hz	1740 Hz
6	430 Hz	860 Hz	1290 Hz	1720 Hz	2150 Hz	2580 Hz